















Ax1  ENCOSTO	Hx4  PARAFUSO
Bx1  ASSENTO	lx8  PARAFUSO
Cx1 (L) x1 (R)  BRAÇOS	Jx8  TAPA FURO
Dx1  SUPORTE	Kx4  ARRUELA
Ex1  PISTÃO (GÁS LIFT)	Lm6x1  CHAVE
Fx1  BASE	Mx4  PEÇA DE ACABAMENTO
Gx5  RODA	



CADEIRA GAMER MGCH-8131-PRETO/AZUL - PART#:MGCH-8131/BL
 CADEIRA GAMER MGCH-8131-PRETO/VERDE - PART#:MGCH-8131/GR
 CADEIRA GAMER MGCH-8131-PRETO/ROSA - PART#:MGCH-8131/PK

CADEIRA GAMER MGCH-8131-PRETO/VERMELHO - PART#:MGCH-8131/RD
 CADEIRA GAMER MGCH-8131-PRETO/BRANCO - PART#:MGCH-8131/WH